

Mirage Retractable Screens Maintenance Recommendations

We recommend the following window screen maintenance and care schedule in order to protect your Mirage retractable window screen for years to come and to minimize unnecessary window screen damage and repair:

- Once a year, use warm soapy water and a soft brush to clean the window screen tracks, housing and mesh.
- Remove unwanted debris such as small stones, dust and pet hair from the bottom track on a regular basis.
- Be sure to lubricate the tracks after each annual cleaning using a high quality silicone lubricant spray.
- Pay careful attention to high traffic and dusty areas where a more frequent cleaning and lubrication schedule may be necessary.
- To help keep your Mirage window screen clean and minimize the chance of damage, it is highly recommended that you retract the window screen into its housing when not in use.